

PART NO. 84100

Instruction Sheet

HYUNDAI REAR CAM KIT

This part should only be installed by personnel who have the necessary skill, training and tools to do the job correctly and safely. Incorrect installation can result in personal injury, vehicle damage and / or loss of vehicle control.

Plan Ahead - Read All Instructions BEFORE installing part

Always check for loose or worn parts, tire pressure and odd tire wear patterns.

1. Raise rear of vehicle and support by frame.
2. Pre-assemble SPC cams by placing one cam washer onto each bolt.
3. **One at a time**, remove factory rear camber/toe bolt assemblies and install SPC bolt/cam.
NOTE: Bolts are different lengths; longer bolt is for camber adjustment.
4. Place second cam washer over protruding end of each bolt and install nut, loosely tighten.
5. Lower vehicle.
6. Adjust alignment angles by turning bolts to achieve desired settings. Once desired setting is achieved, hold bolts from rotating and tighten nuts to 100 lb-ft [136 Nm].
7. Recheck alignment and road test vehicle.

Always check for proper clearance between suspension components and other components of the vehicle.



**Specialty
Products
Company®**

4045 Specialty Pl. • Longmont, CO 80504 • (303) 772-2103
www.specprod.com • www.spcperformance.com

Email: info@specprod.com

Printed in U.S.A. • Rev. 5/17

Toll Free Technical Hot Line: 1-800-525-6505

ECN#2298

©2017 Niwot Corp. dba Specialty Products Co

Form No. 84100INS